



# WARNING!!!

The water level in your pool must not drop lower than below your skimmer.



Lower levels than this and the snow loading can damage the perimeter of the cover due to the excessive stress on the hem.



Low water levels will void the cover warranty.

The most common reason for low water levels is a very small leak in the liner. It is advised to check the water level prior to the first snow fall.