

HAYWARD SKIM-VAC™


MODELS SP1104, SP1105, SP1106 SP1107 SERIES

INSTRUCTIONS

1. Place vacuum cleaner head on vacuum hose and prepare for vacuuming as usual. With pump and filter system operating, fill vacuum hose with water.
2. Keeping water in hose, place hose end over SKIM-VAC hose connection.
3. Insert SKIM-VAC into skimmer and firmly place over basket. Hold SKIM-VAC in place until all air is evacuated from vacuum hose. Once the air is removed, the pump suction will hold the SKIM-VAC firmly in place.
4. To remove SKIM-VAC, merely grasp the hose connection (near the plate) and give a sideward twist or briefly lift vacuum head from pool. This will "break" the suction and allow easy removal.

NOTE:


Take care not to damage or scuff-up SKIM-VAC's specially designed sealing surface. For best results, store the SKIM-VAC in a safe place when not in use.



MODEL SP11052 Furnished with 1-1/2" x 1-1/4" hose elbow. For use on Skimmer Model SP1090, front access style.

MODEL SP11041 Same as above, but with 1-1/4" x 1-1/2" combo hose elbow.

MODEL SP11071 Furnished with 1-1/4" and 1-1/2" combo hose elbow adapter. For use with Skimmer SP1089 front access style.



MODEL SP11051 and 1104 Furnished with 1-1/2" x 1-1/2" hose straight adapter. For use on Skimmer Models SP1096, 1097, 1098, 1099, top cover styles.

MODEL SP11054 Same as above but for 1-1/4" hose.

MODEL SP1106 and 1107 Furnished with 1-1/2" straight hose connection. For use on Skimmer Models SP1082, SP1082(1), 1084 and 1081(1). **MODEL SP11063** For use on SP1070.

NOTE: SP1106 and SP1107 SKIM-VACS, fit 7" baskets. SP11063 fits 8" baskets.



HAYWARD POOL PRODUCTS, INC.

Hayward Pool Products, Inc.
900 Fairmount Avenue
Elizabeth, NJ 07207

Hayward Pool Products, Inc.
2875 Pomona Boulevard
Pomona, CA 91768

Hayward Pool Products Canada
2880 Plymouth Drive
Oakville, Ontario L6H 5R4

Hayward S.A.
Zone Industrielle de Jumet
B - 6040 Charleroi (Belgium)